

## Piping / Cording Foot

"P5" = 5mm Cording Item No: B5002-05A-C-E (BLE8-CF)

"P3" = 3mm Cording Item No: B5002-11A-C-E

### PIPING IN SEAM

#### Machine Settings:

Stitch Type: 4-Thread Overlock

Stitch Width: M -7.5

Needle: O1 and O2

Stitch Length: 3-3.5

Upper Knife: Engaged "UNLOCKED"

Differential Feed: N

Stitch Selector: A

Sewing Speed: Slow to moderate speed

To make covered piping:

Fold bias strip of fabric right side out around the cording and place the cording under the presser foot into the cord guide. Guide the raw edges of the folded bias along the right edge of the needle plate using the knife to trim excess fabric.

To cover and attach piping/cording in fabric seam:

Fold bias strip of fabric right side out around the cording. Sandwich cording between 2 layers of fabric with right sides together.

Place under the presser foot with raw edges to the right and the cording in the cord guide in the sole of the foot. Be sure to guide the cord in the guide while sewing.

### PIPING IN FABRIC CENTER

#### Machine Settings:

Stitch Type: 2-Thread Chain Stitch

Stitch Width: M

Needle: C2 (5mm), C3 (3mm)

Stitch Length: 3-3.5

Upper Knife: Disengaged "LOCKED"

Differential Feed: N

Sewing Speed: Slow to moderate speed

Fold fabric around cording with right side out. Place cording under the presser foot into the cord guide. Stitch C2 chain stitch, guiding the cord and fabric fold into the guide.

#### NOTE:

Try a 7-thread stitch for a completely different corded look.

Use the C1 and C2 cover stitch settings combined with the 4-thread overlock settings.

Place cording between 2 layers of fabric wrong sides together. The edge will finish with the 4-thread overlock while the left narrow cover stitch will sew on the left side of the cord.

